



Silent Switch/Toggle
or Kill switch place?
want to silent booth Midi & Mag

the Mono/Stereo button
on the side should be replaced
with a push toggle button
with led light ...

13Pin Midi goes out on battery
metal plate

Parker Fly Deluxe Modernized Wiring

